



# User's Manual

## EP-USB20 PCI CARD

### TRADEMARKS

All products and company names are trademarks or registered trademarks of their respective holders.

*These specifications are subject to change without notice.*

Manual Revision 1.0  
April 19, 2002

---

## Table of Contents

### ***Chapter 1:***

*Feature ..... 3*

### ***Chapter 2:***

*EP-USB20 Detail Layout ..... 4*

### ***Chapter 3:***

*How to Install PCI Card ..... 5*

### ***Chapter 4:***

*How to Install Driver ..... 6*

## Mainboard Features

- ◆ **Host Controller**

- VIA VT6202


- ◆ **Features**

- Standard compliant with USB specification ver 2.0 and ver 1.1
- Supports High speed data rate up to 480 Mbps
- 3 External Type A USB ports
- Supports up to 127 downstream USB devices
- Enables Plug and Play installation




- ◆ **Board Dimension**

- 120mm x 70mm

## EP-USB20 Detail Layout



## How to Install EP-USB20 In PCI Slot



### How to Install Driver

#### Driver Installation (Windows XP/Windows 2000)

Setp1: First, please make sure the PCI card has been installed correctly.


Setp2: Please insert the “Windows 2000/Windows XP USB 2.0 Driver Installation diskette”. Double click on the “setup .exe” file to execute the setup program.

Setp3: Please restart your system when the installation is completed. You can select “Device Manager” and check the function on your device.

**Note:** In your “*Device Manager*” if there is a yellow exclamation on “*VIA USB2.0 Enhanced Host Controller*” or “*USB2.0 Root Hub Device*”, please click the “*Uninstall*” button to remove this item from the “*Device Manager*” and click “*Refresh*” to re-install this driver again.

---

## Windows XP Drive Installation Complete



---

## Windows 2000 Driver Installation Complete

